

### PLUG AND RECEPTACLE ASSEMBLY

#### **TERMINAL INSERTION**



Grasp the terminal approximately
1 inch (25.4mm) behind insulation crimp.




Hold the connector with the wire seal grommet facing the terminal.

**Note:** For unused wire cavities, insert sealing plugs for full environmental sealing.



Push the terminal straight into the connector until a positive stop is felt. A slight tug will confirm that it is properly locked into place.



TERMINAL BEING PUSHED INTO THE LOCKING MECHANISM

TERMINAL



TERMINAL LOCKED INTO POSITION

**REVISION:** 

**ECR/ECN INFORMATION:** 

EC No: WNA2010-0052

DATE: 2009 / 07 / 22

TITLE:

ASSEMBLY INSTRUCTIONS
FOR XRC<sup>™</sup> (EXTRA RUGGED CIRCULAR)
SEALED CONNECTORS

SHEET No.

**1** of **4** 

DOCUMENT NUMBER:

AS-84501-001

CREATED / REVISED BY:
W. LEUNG


CHECKED BY: T. MOELLER

APPROVED BY: **D. TITUS** 




### PLUG AND RECEPTACLE ASSEMBLY

#### TERMINAL EXTRACTION




Hold the connector with the wire seal grommet facing the appropriate size extractor tool. Snap the tool onto the terminal wire.



Slide tool along the wire into the insert cavity until it engages the terminal and resistance is felt.

Note: Do not twist or insert tool at an angle.




Pull the terminal wire lead along with the tool out of the connector.

#### **EXTRACTION TOOL**



### **EXTRACTION TOOL INSERTED** TO UNLOCK TERMINAL



### TOOL AND TERMINAL BEING REMOVED

**REVISION:** 

**ECR/ECN INFORMATION:** 

EC No: WNA2010-0052

DATE: 2009 / 07 / 22

TITLE:

**ASSEMBLY INSTRUCTIONS** FOR XRC<sup>™</sup> (EXTRA RUGGED CIRCULAR) **SEALED CONNECTORS** 

SHEET No.

2 of 4

DOCUMENT NUMBER:

AS-84501-001

CREATED / REVISED BY: W. LEUNG

CHECKED BY:

T. MOELLER

APPROVED BY: D. TITUS




## MATING/UNMATING PROCEDURE FOR XRC<sup>™</sup> 18-14 CONNECTOR

- A. TO MATE THE PLUG TO THE RECEPTACLE -
  - 1. LINE UP THE BLACK VISUAL ALIGNMENT SQUARE ON THE PLUG WITH EITHER THE FLAT SURFACE OR THE BLACK VISUAL ALIGNMENT SQUARE ON THE RECEPTACLE.
  - 2. TURN THE COUPLING RING 1/4 TURN CLOCKWISE UNTIL A POSITIVE STOP IS FELT.



BLACK VISUAL ALIGNMENT SQUARE



NOTE: THERE WILL BE A TACTILE AND AUDIBLE FEEDBACK WHEN MATED CORRECTLY.


B. TO UNMATE THE PLUG FROM THE RECEPTACLE, REVERSE THE ABOVE PROCEDURE.

REVISION:	ECR/ECN INFORMATION: EC No: WNA2010-0052  DATE: 2009 / 07 / 22	ASSEMBLY INSTRUCTIONS FOR XRC <sup>TM</sup> (EXTRA RUGGED CIRCULAR) SEALED CONNECTORS			3 of <b>4</b>		
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	APPROVED BY:			
AS-84501-001		W. LEUNG	T. MOELLER	D. TITUS			
TEMPLATE FUENAME, APPLICATION OPERIORE AND ADDRESS AND							



## MATING/UNMATING PROCEDURE FOR XRC<sup>™</sup> 24-31 CONNECTOR

- A. TO MATE THE PLUG TO THE RECEPTACLE -
  - 1. LINE UP THE VISUAL ALIGNMENT RAISED TAB ON THE PLUG WITH EITHER THE FLAT SURFACE OR THE VISUAL ALIGNMENT RAISED TAB ON THE RECEPTACLE.
  - 2. TURN THE COUPLING RING 1/4 TURN CLOCKWISE UNTIL A POSITIVE STOP IS FELT.



## B. TO UNMATE THE PLUG FROM RECEPTACLE, REVERSE THE ABOVE PROCEDURE.

REVISION:	ECR/ECN INFORMATION: EC No: WNA2010-0052  DATE: 2009 / 07 / 22	ASSEMBLY INSTRUCTIONS FOR XRC <sup>TM</sup> (EXTRA RUGGED CIRCULAR) SEALED CONNECTORS			<u>SHEET No.</u> <b>4</b> of <b>4</b>
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	APPROVED BY:	
AS-84501-001		W. LEUNG	T. MOELLER	D. TITUS	